




Setup instructions

1. Mount the fittings on the power circuit
2. Place the power circuit on the truss system
3. Mount the lamps where you want them
4. Connect to power with the power cable
 - if you have multiple power circuit, you connect them with the connector cable.

Important to know...

When mounting your lamps, the lock needs to be placed on the elevated side of the power circuit. The lamp cannot be locked onto the circuit if not placed correct. The lamp is mounted by turning the lock 90°.

The lamp should be set to **"off"** when mounting and demounting from the circuit. Switch on the lamp by turning the castor to **"3"**.



QR-code



Scan the code and see how you mount X-zoom light

